

1. Getting Started

1.1. Hardware Setup

1.1.1. Please use switch to connect the LAN of computer and device. Do not connect computer and device directly.


1.2. Manager Utility

1.2.1. Install Manager Utility

1.2.2. Start Manager Utility

1.2.2.1. Change the properties of the Manager Utility


Click right-hand button → properties → check “Run this program in compatibility mode for” windows XP, and “Run this program as an administrator” → Apply




1.2.3. Allow access both “Private” and “Public”. It is important for upgrade.




1.2.3.1. Main



1.2.3.2. Search&configure tool,




1.2.3.2.1. Double-click to enter configure




1.2.3.2.2. Command button

1.2.3.2.2.1. Upgrade firmware → select file




Continue to upgrade → OK




Wait to upgrade finished



1.2.3.2.2.2. Devices List → Convert web data



1.2.3.2.2.3. Convert web data → upload → ialarm.anf → Upload



1.2.3.2.2.4.

<http://192.168.2.127:5003/ialarm.html> is accessible now