

Content

1. Getting Started.....	1
1.1. Hardware Setup	1
1.2. Manager Utility	1

1. Getting Started

1.1. Hardware Setup

- 1.1.1. Please use switch to connect the LAN of computer and device. Do not connect computer and device directly.


1.2. Manager Utility

- 1.2.1. Install Manager Utility

- 1.2.2. Start Manager Utility

- 1.2.2.1. Change the properties of the Manager Utility


Click right-hand button → properties → check “Run this program in compatibility mode for” windows XP, and “Run this program as an administrator” → Apply




1.2.3. Allow access both “Private” and “Public”. It is important for upgrade.




1.2.3.1. Main



1.2.3.2. Search&configure tool,




1.2.3.2.1. Double-click to enter configure



1.2.3.2.2. Command button

1.2.3.2.2.1. Upgrade firmware → select file




Continue to upgrade → OK




Wait to upgrade finished



1.2.3.2.2.2. Devices List → Convert web data



1.2.3.2.2.3. Convert web data → upload → ictrl.anf → 按 Upload 按钮



1.2.3.2.2.4.

<http://192.168.2.127:5003/iconrol.html> is accessable now